

## **Hybrid Inverter**

SUN-5K-SG02LP1-AU-AM2

SUN-6K-SG02LP1-AU-AM2

SUN-7.6K-SG02LP1-AU-AM2

SUN-8K-SG02LP1-AU-AM2

SUN-10K-SG02LP1-AU-AM3

SUN-12K-SG02LP1-AU-AM3

**User Manual** 



# **Contents**

1. Safety Introductions		01
2. Product instructions		02-04
2.1 Product Overview		
2.2 Product Size		
2.3 Product Features		
2.4 Basic System Architecture		
2.5 Maintenance of the System	n	
3. Installation		05-21
3.1 Parts list		
3.2 Mounting instructions		
3.3 Battery connection		
3.4 Grid connection and back	rup load connection	
3.5 PV Connection		
3.6 CT Connection		
<ul><li>3.6.1 Meter Connection</li><li>3.7 Earth Connection(manda</li></ul>	tory)	
3.8 WIFI Connection	itory)	
3.9 Communication Connec	tion	
3.10 Wiring System for Inver-		
3.11 Typical application diag		22
-		22
4.1 Power ON/OFF	1	
4.2 Operation and Display Pa		
1 )		23-37
5.1 Main Screen		
5.2 Solar Power Curve	0.011	
5.3 Curve Page-Solar & Load	& Grid	
5.4 System Setup Menu		
5.5 Basic Setup Menu		
5.6 Battery Setup Menu	a Maria	
5.7 System Work Mode Setup	5 Menu	
<ul><li>5.8 Grid Setup Menu</li><li>5.9 Generator Port Use Setup</li></ul>	a Manu	
5.10 Advanced Function Setu		
5.11 Device Info Setup Menu		
6. Mode	·	37-38
7. Fault information and p		39-41
	g	
9. Datasheet		
	t inverter	
11 Disposing of the inver	ter	43 43
11. Disposing of the inver	tei	45
12. Appendix I		44-46
13. Appendix II ·····		47

#### **About This Manual**

The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.

#### How to Use This Manual

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times.

Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice. The latest manual can be acquired via service@deye.com.cn

## 1. Safety Introductions

## Safety signs



The DC input terminals of the inverter must not be grounded.



Surface high temperature, Please do not touch the inverter case.





The AC and DC circuits must be disconnected separately, and the maintenance personnel

must wait for 5 minutes before they are completely powered off before they can start working.



Prohibit disassembling inverter case, there existing shock hazard, which may cause serious injury or death, please ask qualified person to repair.



Please read the instructions carefully before use.




Do Not put it in the waste bin! Recycle it by licensed professional!

- · This chapter contains important safety and operating instructions. Read and keep this manual for future reference.
- Before using the inverter, please read the instructions and warning signs of the battery and corresponding sections in the instruction manual.
- · Do not disassemble the inverter. If you need maintenance or repair, take it to a professional service center.
- · Improper reassembly may result in electric shock or fire.
- · To reduce risk of electric shock, disconnect all wires before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- · Caution: Only qualified personnel can install this device with battery.
- · Never charge a frozen battery.
- · For optimum operation of this inverter, please follow required specification to select appropriate cable size. It is very important to correctly operate this inverter.
- · Be very cautious when working with metal tools on or around batteries. Dropping a tool may cause a spark or short circuit in batteries or other electrical parts, even cause an explosion.
- · Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to "Installation" section of this manual for the details.
- · Grounding instructions this inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- Never cause AC output and DC input short circuited. Do not connect to the mains when DC input short circuits.

## 2. Product Introductions

This is a multifunctional inverter, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user configurable and easy accessible button operation such as battery charging, AC/solar charging, and acceptable input voltage based on different applications.

#### 2.1 Product Overview



1: Inverter Indicators

2: LCD display

3: Function Buttons

4: DC Switch

5: Power on/off button

6: BMS 485/CAN port

7: DRMs Port

8: Battery input connectors

9: Function Port

10: Meter port

11: Parallel port

12: PV input


13: Grid


14: Generator input

15: Load

16: WiFi Interface

## 2.2 Product Size





#### 2.3 Product Features

- Self-consumption and feed-in to the grid.
- Auto restart while AC is recovering.
- Programmable supply priority for battery or grid.
- Programmable multiple operation modes: On grid, off grid and UPS.
- Configurable battery charging current/voltage based on applications by LCD setting.
- Configurable AC/Solar/Generator Charger priority by LCD setting.
- Compatible with mains voltage or generator power.
- Overload/over temperature/short circuit protection.
- Smart battery charger design for optimized battery performance
- With limit function, prevent excess power overflow to the grid.
- Supporting WIFI monitoring and build-in 2 strings of MPP trackers
- Smart settable three stages MPPT charging for optimized battery performance.
- Time of use function.
- Smart Load Function.

## 2.4 Basic System Architecture

The following illustration shows basic application of this inverter.

It also includes following devices to have a Complete running system.


- Generator or Utility
- PV modules
- Battery

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as refrigerator and air conditioner.

## 2.5 Maintenance of the System


The inverter is low maintenance, however, it is important that at least twice a year (for dusty environments this may need to be carried out weekly) all the cooling fans, air ducts are cleaned and dust free. Check if there are no fault codes and Lithium battery communication is correct. Weekly cleaning statement: Suggest micromesh filters as an available option.



## 3. Installation

#### 3.1 Parts List

Check the equipment before installation. Please make sure nothing is damaged in the package. You should have received the items in the following package:





Stainless steel anti-collision bolt M8×80 x4





Parallel communication cable x1


















\*One for BMS communication cable, and another two for AC wires.

Magnetic ring for battery x 1

Magnetic ring x3\*


## 3.2 Mounting instructions

#### **Installation Precaution**

This Hybrid inverter is designed for outdoor use(IP65), Please make sure the installation site meets below conditions:


- · Not in direct sunlight
- · Not in areas where highly flammable materials are stored.
- · Not in potential explosive areas.
- · Not in the cool air directly.
- · Not near the television Antenna or antenna cable.
- · Not higher than altitude of about 2000 meters above sea level.
- · Not in environment of precipitation or humidity(>95%)

Please AVOID direct sunlight, rain exposure, snow laying up during installation and operation. Before connecting all wires, please take off the metal cover by removing screws as shown below:



## Considering the following points before selecting where to install:

- · Please select a vertical wall with load-bearing capacity for installation, suitable for installation on concrete or other non-flammable surfaces, installation is shown below.
- · Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature is recommeded to be between -40~60°C to ensure optimal operation.
- · Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and have enough space for removing wires.




For proper air circulation to dissipate heat, allow a clearance of approx. 50cm to the side and approx. 50cm above and below the unit. And 100cm to the front.

## Mounting the inverter

Remember that this inverter is heavy! Please be careful when lifting out from the package. Choose the recommend drill head(as shown in below pic) to drill 4 holes on the wall, 82-90mm deep.

- 1. Use a proper hammer to fit the expansion bolt into the holes.
- 2. Carry the inverter and holding it, make sure the hanger aim at the expansion bolt, fix the inverter on the wall.
- 3. Fasten the screw head of the expansion bolt to finish the mounting.



## 3.3 Battery connection

For safe operation and compliance, a separate DC over-current protector or disconnect device is required between the battery and the inverter. In some applications, switching devices may not be required but over-current protectors are still required. Refer to the typical amperage in the table below for the required fuse or circuit breaker size.

Model	Wire Size	Cable(mm²)	Torque value(max)
5/6kW	2AWG	35	24.5Nm
7.6/8kW	1AWG	50	24.5Nm
10/12kW	0AWG	55	24.5Nm

Chart 3-2 Cable size




All wiring must be performed by a professional person.



Connecting the battery with a suitable cable is important for safe and efficient operation of the system. To reduce the risk of injury, refer to Chart 3-2 for recommended cables.

Please follow below steps to implement battery connection:

- 1. Please choose a suitable battery cable with correct connector which can well fit into the battery terminals.
- 2. Use a suitable screwdriver to unscrew the bolts and fit the battery connectors in, then fasten the bolt by the screwdriver, make sure the bolts are tightened with torque of 24.5 N.M in clockwise direction
- 3. Make sure polarity at both the battery and inverter is correctly connected.



4. In case of children touch or insects go into the inverter, Please make sure the inverter connector is fasten to waterproof position by twist it clockwise.





Installation must be performed with care.




Before making the final DC connection or closing DC breaker/disconnect, be sure positive(+) must be connect to positive(+) and negative(-) must be connected to negative(-). Reverse polarity connection on battery will damage the inverter.

## 3.3.2 Function port definition







TEMP (1,2): battery temperature sensor for lead acid battery.

CT-L1 (3,4): current transformer (CT1) for "zero export to CT"mode clamps on L1 when in split phase system.

CT-L2 (5,6): current transformer (CT2) clamps on L2 when in split phase system or clamps on the only live line when in single phase system for "zero export to CT" mode.


G-start (7,8): dry contact signal for startup the diesel generator.

When the "GEN signal" is active, the open contact (GS) will switch on (no voltage output). G-valve (9,10): reserved.

RSD (11+,12-): provide 12Vdc output when inverter is on.

ATS: If the conditions are met, it will output 230Vac.

Note: For - AU model, 1pcs CT is needed only, and the secondary side of the CT should be connected to 5&6 port (CT-L2).




BMS 485/CAN: for battery communication. Meter: for energy meter communication.

Parallel A: Parallel communication port 1 (CAN interface).


Parallel B: Parallel communication port 2 (CAN interface).

DRMs: Logic interface for AS/NZS 4777.2:2020



GS (diesel generator startup signal)

## 3.3.3 Temperature sensor connection for lead-acid battery



## 3.4 Grid connection and backup load connection

- · Before connecting to the grid, a separate AC breaker must be installed between the inverter and the grid, and also between the backup load and the inverter. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current. For the 5/6/7.6/8/10/12kW model, the recommended AC breaker for backup load 5/6kW is 40A, 7.6/8kW is 63A, 10/12kW is 100A. For the 5/6/7.6/8/10/12kW model, the recommended AC breaker for grid 5/6kW is 40A, 7.6/8kW is 63A, 10/12kW is 100A. In final installation, breaker certified according to AS60947.3 shall be installed with the equipment.
- · There are three terminal blocks with "Grid" "Load"and "GEN" markings. Please do not misconnect input and output connectors.




All wiring must be performed by a qualified personnel. It is very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable as below.


Model	Wire Size	Cable(mm²)	Torque value(max)
5/6kW	8AWG	8	1.2Nm
7.6/8kW	7.6/8kW 6AWG		1.2Nm
10/12kW	10/12kW 4AWG		1.2Nm

Chart 3-3 Recommended Size for AC wires

## Please follow below steps to implement AC input/output connection:

- Before making Grid, load and Gen port connection, be sure to turn off AC breaker or disconnector first.
- Remove insulation sleeve 10mm length, unscrew the bolts, insert the wires according to polarities indicated on the terminal block and tighten the terminal screws. Make sure the connection is complete.







Be sure that AC power source is disconnected before attempting to wire it to the unit.

- 3. Then, insert AC output wires according to polarities indicated on the terminal block and tighten terminal. Be sure to connect corresponding N wires and PE wires to related terminals as well.
- 4. Make sure the wires are securely connected.
- 5. Appliances such as air conditioner are required at least 2-3 minutes to restart because it is required to have enough time to balance refrigerant gas inside of circuit. If a power shortage occurs and recovers in short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it is equipped with time-delay function before installation. Otherwise, this inverter will trigger overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner

#### 3.5 PV Connection

The PV modules used to connected to this inverter shall be Class A rating certified according to IEC 61730.

Before connecting to PV modules, please install a separately DC circuit breaker between inverter and PV modules. It is very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Wire Size	Cable(mm²)
5/6/7.6/8/10/12kW	12AWG	4

Chart 3-4 Cable size



To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.



It is requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

#### 3.5.1 PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

- 1) Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
- 2) Open circuit Voltage (Voc) of PV modules should be higher than min. start voltage.

Inverter Model	5kW	6kW	7.6kW	8kW	10kW	12kW
PV Input Voltage	370V (125V~500V)					
PV Array MPPT Voltage Range	150V-425V					
No. of MPP Trackers	2				3	3
No. of Strings per MPP Tracker		2+2			2+2	2+2

Chart 3-5




#### Note:


This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring. If an Earth Fault Alarm occurs, the inverter will not connect to the grid and will report an error F04 on its LCD. At the same time, the buzzer will sound. For the machine installed with Wi-Fi/GPRS, the alarm informa on can be seen on the corresponding monitoring website, and can also be received by the APP on the mobile phone.


#### 3.5.2 PV Module Wire Connection:


Please follow below steps to implement PV module connection:

- 1. Remove insulation sleeve 10 mm for positive and negative conductors.
- Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool.
- 3. Check correct polarity of wire connection from PV modules and PV input connectors. Then, connect positive pole (+) of connection wire to positive pole (+) of PV input connector. Connect negative pole (-) of connection wire to negative pole(-) of PV input connector. Close the switch and make sure the wires are tightly fixed.












#### Note:

linverter has built—in leakage current detection circuit, If an external RCD is required, a type-A RCD with rated residual current of 300mA or higher is suggested. Otherwise inverter may not work properly

## 3.7 Earth Connection(mandatory)

Ground cable shall be connected to ground plate on grid side, this prevents electric shock if the original protective conductor fails.



Model	lel Wire Size Cable(ı		Torque value(max)
5/6kW	8AWG	8	1.2Nm
7.6/8kW	6AWG	13	1.2Nm
10/12kW	5AWG	16	1.2Nm

#### 3.8 WIFI Connection

For the configuration of Wi-Fi Plug, please refer to illustrations of the Wi-Fi Plug. The Wi-Fi Plug is not a standard configuration, it's optional.

For WIFI configuration, please check the manual of "Wi-Fi-Plug configuration manual".

For web monitoring, please visit: https://www.deyecloud.com.

For mobile monitoring, please scan the QR code to down load the APP.



## Deye Cloud

All in one, Efficiency



Scan QR code to download APP



#### 3.9 Communication Connection


#### 1.BMS


Please connect the cable to BMS CAN port to realize BMS communication. Otherwise, BMS communication may fail. Please refer to Annex I for the interface pin definition of BMS RJ45 port.

#### 2.DRM (Only DRM0 is available)


In Australia and New Zealand, the inverter supports the demand response modes as specified in the standard AS/NZS 4777. Please refer to Annex I for the interface pin definition of DRM RJ45 port.

## 3.10 Wiring System for Inverter





## 3.11 Typical application diagram of diesel generator



② AC Breaker for gen port SUN-5K-SG-AU: 40A AC breaker SUN-6K-SG-AU: 40A AC breaker SUN-7.6K-SG-AU: 63A AC breaker SUN-8K-SG-AU: 100A AC breaker SUN-12K-SG-AU: 100A AC breaker

- 21 -

#### 4. OPERATION

#### 4.1 Power ON/OFF

Once the system has been properly installed and the battery is connected to the inverter, follow the steps below to turn on the inverter:

- 1. Turn all the breakers of the installation on.
- 2. Turn on the DC switch of the inverter and the power button of battery (If there is one battery installed at the system), no matter the order.
- 3. Press the ON/OFF button (located on the left side of the inverter case) to turn on the inverter. When a system connected to either PV or Grid (without battery) is switched on, the LCD will still be lighted up displaying "OFF". In this situation, after switching ON/OFF button on, select "NO batt" at the inverter settings to make the system work.

When turning off the inverter, please follow the following steps:

- 1. Turn off the AC breakers on Grid port, Load port and GEN port.
- 2. Press the ON/OFF button of hybrid inverter and turn off the DC breaker on battery side, turn off power button of the battery.
- 3. Switch off the DC switch.

NOTE: Choose the correct country code. (refer to section 5.8 of this manual) Notice: Different distribution network operators in different countries have different requirements regarding grid connections of PV grid connected inverters. Therefore, it's very important to make sure that you have selected the correct country code according to requirements of local authority. Please consult gualified electrical engineer or personnel from electrical safety authorities about this.

## 4.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes four indicators, four function keys and a LCD display, indicating the operating status and input/output power information.

L	ED Indicator	Messages		
DC	Green led solid light	PV Connection normal		
AC	Green led solid light	Grid Connection normal		
Normal	Green led solid light	Inverter operating normal		
Alarm	Red led solid light	Malfunction or warning		

Chart 4-1 LED indicators


Function Key	Description				
Esc	To exit setting mode				
Up	To go to previous selection				
Down	To go to next selection				
Enter	To confirm the selection				

Chart 4-2 Function Buttons

## 5. LCD Display Icons


#### 5.1 Main Screen

The LCD is touchscreen, below screen shows the overall information of the inverter.




- 1.The icon in the center of the home screen indicates that the system is Normal operation. If it turns into "comm./F01~F64", it means the inverter has communication errors or other errors, the error message will display under this icon(F01-F64 errors, detail error info can be viewed in the System Alarms menu).
- 2.At the top of the screen is the time.
- 3.System Setup Icon, Press this set button, you can enter into the system setup screen which including Basic Setup, Battery Setup, Grid Setup, System Work Mode, Generator port use, Advanced function and Li-Batt info.
- 4.The main screen showing the info including Solar, Grid, Load and Battery. Its also displaying the energy flow direction by arrow. When the power is approximate to high level, the color on the panels will changing from green to red so system info showing vividly on the main screen.
- · PV power and Load power always keep positive.
- · Grid power negative means sell to grid, positive means get from grid.
- · Battery power negative means charge, positive means discharge.

## 5.1.1 LCD operation flow chart




#### 5.2 Solar Power Curve



#### This is Solar Panel detail page.

- (1) Solar Panel Generation.
- ② Grid Tie Power: when there's a string inverter AC couple at the grid or load side of hybrid inverter and there's a meter installed for the string inverter, then the hybrid inverter LCD will show the string inverter output power on its PV icon. Please make sure the meter can communicate with the hybrid inverter successfully.
- 3 Voltage, Current, Power for each MPPT.
- 4 Solar Panel energy for Day and Total.

Press the "Energy "button will enter into the power curve page.



#### This is Inverter detail page.

- 1 Inverter Generation.
- 0.0Hz: frequency after DC/AC.
   Voltage, Current, Power for each Phase.
- 3 \*DC-T: mean DC-DC temperature,

AC-T: mean Heat-sink temperature.

\*Note: this part info is not available for some LCD FW.



#### This is Load detail page.

- 1 Load Power.
- 2 Voltage, Power for each Phase.
- 3 Load consumption for Day and Total.

When you check "Selling First" or "Zero export to Load" on system work mode page, the information on this page is about backup load which connect on Load port of hybrid inverter.

When you check "Zero export to CT" on system work mode page, the information on this page is including backup load and home load.

Press the "Energy" button will enter into the power curve page.



#### This is Grid detail page.


- 1 Status, Power, Frequency.
- 2 L1&L2: Voltage for each Phase CT1&CT2: External Current Sensor Power LD1&LD2: Internal Current Sensor Power.
- 3 BUY: Energy from Grid to Inverter, SELL: Energy from Inverter to Grid.

Press the "Energy " button will enter into the power curve page.



This is Battery detail page.


if you use Lithium Battery, you can enter BMS page.




**Request Force Charge:** It indicates the BMS requests hybrid inverter to charge the battery actively.


L	.i-BN	/IS							
	Volt	Curr	Temp	soc	Energy	Cha Volt	rge Curr	Fault	
	50.38V		30.6C	52.0%	26.0Ah	0.00	0.0A	0 0 0	
	50.33V	19.10A	31.0C	51.0%	25.5Ah	53.2V	25.0A	0 0 0	Sum
	50.30V	16.90A	30.2C	12.0%	6.0Ah	53.2V	25.0A	0 0 0	
	0.00V	0.00A		0.0%	0.0Ah				Data
									$\equiv$
									Details
									Data
									ㄷ

## 5.3 Curve Page-Solar & Load & Grid










Solar power curve for daily, monthly, yearly and total can be roughly checked on the LCD, for more accuracy power generation, pls check on the monitoring system. Click the up and down arrow to check power curve of different period.

## 5.4 System Setup Menu



This is System Setup page.

## 5.5 Basic Setup Menu




Factory Reset: Reset all parameters of the inverter. Lock out all changes: Enable this menu for setting parameters that require locking and cannot be set up. Before performing a successful factory reset and locking the systems, to keep all changes you need to type in a password to enable the setting.



System selfchek: After ticking this item, it needs input the password.

## 5.6 Battery Setup Menu



**Battery capacity:** it tells Deye hybrid inverter to know your battery bank size.

Use Batt V: Use Battery Voltage for all the settings (V). Use Batt %: Use Battery SOC for all the settings (%). Max. A charge/discharge: Max battery charge/discharge current(0-120A for 5kW model, 0-135A for 6kW model, 0-190A for 7.6/8kW model, 0-220A for 10kW model, 0-250A for 12kW model).

For AGM and Flooded, we recommend Ah battery size x 20%= Charge/Discharge amps.


. For Lithium, we recommend Ah battery size x 50% = Charge/Discharge amps.

. For Gel, follow manufacturer's instructions.

No Batt: tick this item if no battery is connected to the system.

**Active battery:** This feature will help recover a battery that is over discharged by slowly charging from the solar array or grid.

**Disable Float Charge:** For the lithium battery with BMS communication, the inverter will keep the charging voltage at the current voltage when the BMS charging current requested is 0. It is used to help prevent battery from being overcharged.



This is Battery Setup page.

(1)(3)

**Start =30%:** Percent S.O.C at 30% system will AutoStart a connected generator to charge the battery bank.

**A** = **40A**: Charge rate of 40A from the attached generator in Amps.

**Gen Charge:** uses the gen input of the system to charge battery bank from an attached generator.

**Gen Signal:** Normally open relay that closes when the Gen Start signal state is active.

**Gen Force:** When the generator is connected, it is forced to start the generator without meeting other conditions.

#### This is Grid Charge, you need select. (2)


Start =30%: No use, Just for customization.

A = 40A: It indicates the Current that the Grid charges the Battery.


**Grid Charge:** It indicates that the grid charges

the battery.


Grid Signal: Disable.



This page tells the PV and diesel generator power the load and battery.



This page tells generator output voltage, frequency, power. And, how much energy is used from generator.




**Lithium Mode:** This is BMS protocol.Please reference the document(Approved Battery).

**Shutdown 10%:** It indicates the inverter will shutdown if the SOC below this value.

**Low Batt 20%:** It indicates the inverter will alarm if the SOC below this value.

**Restart 40%:** Battery voltage at 40% AC output will resume.



#### There are 3 stages of charging the Battery.

1

This is for professional installers, you can keep it if you do not know.

2

**Shutdown 20%:** The inverter will shutdown if the SOC below this value.

**Low Batt 35%:** The inverter will alarm if the SOC below this value.

3

Restart 50%: Battery SOC at 50% AC output will resume.

#### Recommended battery settings

Battery Type	Absorption Stage	Float Stage	Equalization Voltage (every 30 days 3hr )		
AGM (or PCC)	14.2V (57.6V)	13.4V (53.6V)	14.2V (57.6V)		
Gel	14.1V (56.4V)	13.5V (54.0V)			
Wet	14.7V (59.0V)	13.7V (55.0V)	14.7V (59.0V)		
Lithium	Follow its BMS voltage parameters				

#### 5.7 System Work Mode Setup Menu




#### Work Mode

Selling First(Generation limit control): This Mode allows hybrid inverter to sell back any excess power produced by the solar panels to the grid. If time of use is active, the battery energy also can be sold into grid.


The PV energy will be used to power the load and charge the battery and then excess energy will flow to grid. Power source priority for the load is as follows:

- 1. Solar Panels.
- 2. Grid.
- 3. Batteries (until programable % discharge is reached).

**Zero Export To Load:** Hybrid inverter will only provide power to the backup load connected. The hybrid inverter will neither provide power to the home load nor sell power to grid. The built-in CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load and charge the battery.



Zero Export To CT(Export limit control): Hybrid inverter will not only provide power to the backup load connected but also give power to the home load connected. If PV power and battery power is insufficient, it will take grid energy as supplement. The hybrid inverter will not sell power to grid. In this mode, a CT is needed. The installation method of the CT please refer to chapter 3.6 CT Connection. The external CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load, charge battery and home load.



Selling First is Generation limit control function, which limits the amount of power generated by the inverter. In this state Max. sell power is the soft limit of the maximum apparent power that the inverter can generate, and Zero-export Power is the hard limit of the maximum apparent power that the inverter can generate.

Zero Export To CT is Export limit control function, it can limit the inverter export to grid active power. max. sell power is soft limit inverter export to grid max. active power, Zero-export Power is hard limit inverter export to grid.



#### Note:

Customer can only use export limit control function by CT or meter.

**Solar Sell:** "Solar sell" is for Zero export to load or Zero export to CT: when this item is active, the surplus energy can be sold back to grid. When it is active, PV Power source priority usage is as follows: load consumption and charge battery and feed into grid.

Max. sell power: Allowed the maximum output power to flow to grid.

**Zero-export Power:** for zero-export mode, it tells the grid output power. Recommend to set it as 20-100W to ensure the hybrid inverter won't feed power to grid.


Energy Pattern: PV Power source priority.


**Batt First:** PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

**Load First:** PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Max Solar Power: allowed the maximum DC input power.

**Grid Peak-shaving:** when it is active, grid output power will be limited within the set value. If the load power exceeds the allowed value, it will take PV energy and battery as supplement. If still can't meet the load requirement, grid power will increase to meet the load needs.





Time of use: it is used to program when to use grid or generator to charge the battery, and when to discharge the battery to power the load. Only tick "Time Of Use" then the follow items (Grid, charge, time, power etc.) will take effect.

**Note:** when in selling first mode and click time of use, the battery power can be sold into grid.

**Grid charge:** utilize grid to charge the battery in a time period.

**Gen charge:** utilize diesel generator to charge the battery in a time period.

Time: real time, range of 01:00-24:00.

Power: Max. discharge power of battery allowed. Batt(V or SOC %): battery SOC % or voltage at when the action is to happen.

#### For example:


During 01:00-05:00, when battery SOC is lower than 80%, it will use grid to charge the battery until battery SOC reaches 80%.

During 05:00-08:00 and 08:00-10:00, when battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 10:00-15:00, when battery SOC is higher than 80%, hybrid inverter will discharge the battery until the SOC reaches 80%.

During 15:00-18:00, when battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 18:00-01:00, when battery SOC is higher than 35%, hybrid inverter will discharge the battery until the SOC reaches 35%.



It allows users to choose which day to execute the setting of "Time of Use".

For example, the inverter will execute the time of use page on Mon/Tue/Wed/Thu/Fri/Sat only.

## 5.8 Grid Setup Menu

## 5.8.1 Commissioning Procedure

If all physical connection is checked ok, please follow the steps below.


- 1.Turn on AC circuit breaker.
- 2.Turn on DC circuit breaker on PV strings and battery.
- 3. Turn on circuit breaker on battery pack.
- 4. Turn on DC switch on the inverter
- 5. Check the inverter status by inverter indicators and battery status by battery indicators.



#### Note

The inverter has not been tested to AS/NZS 4777.2:2020 for multiple inverter combinations and/or multiple phase inverter combinations such combinations should be used or external devices should be used in accordance with the requirements of AS/NZS 4777.1

#### 5.8.2 Grid Standard Selection



**Unlock Grid Setting:** before changing the grid parameters, please enable this with password. Then it is allowed to change the grid parameters.

Grid Mode: General Standard、UL1741 & IEEE1547、
CPUC RULE21、SRD-UL-1741、CEI 0-21、EN50549\_CZ、
Australia\_A、Australia\_B、Australia\_C、NewZealand、
VDE4105、OVE\_Directive\_R25、EN50549\_CZ\_PPDS\_L16A、
NRS097、G98/G99、G98/G99\_NI、ESB Networks(Ireland).
Please follow the local grid code and then choose the corresponding grid standard.

For The Australian Market:

For compliance with AS/NZS 4777.2:2020 please select from

• Australia A • Australia B • Australia C • New Zealand

Please contact your local grid operator for which option to select


Note: By selecting Australia A, Australia B or Australia C the power quality response mode and grid protection settings will be reset to their default values for Australia RegionA, B, C respectively.

## Default volt-watt settings for different regions are shown in the following table:

Region	Default value	$Vw_1$	Vw₁-ch	Vw <sub>2</sub>	Vw <sub>2</sub> -ch
A stratic A	Voltage	253V	207V	260V	215V
Australia A	Inverter maximum active power output level(P) % of Srated	100%	20%	20%	100%
	Voltage	250V	195V	260V	215V
Australia B	Inverter maximum active power output level(P) % of Srated	100%	0%	20%	100%
	Voltage	253V	207V	260V	215V
Australia C	Inverter maximum active power output level(P) % of Srated	100%	20%	20%	100%
	Voltage	242V	216V	250V	224V
New Zealand	Inverter maximum active power output level(P) % of Srated	100%	20%	20%	100%

## Default volt-var settings for different regions are shown in the following table:

Region	Default value	$Vv_1$	$Vv_2$	Vv <sub>3</sub>	Vv <sub>4</sub>
A	Voltage	207V	220V	240V	258V
Australia A	Inverter maximum active power output level(P) % of S <sub>rated</sub>	44%supplying	0%	0%	60%absorbing
	Voltage	205V	220V	235V	255V
Australia B	Inverter maximum active power output level(P) % of Srated	30%supplying	0%	0%	40%supplying
	Voltage	215V	230V	240V	255V
Australia C	Inverter maximum active power output level(P) % of Srated	44%supplying	0%	0%	60%supplying
	Voltage	207V	220V	235V	244V
New Zealand	Inverter maximum active power output level(P) % of Srated	60%supplying	0%	0%	60%supplying




**Normal connect**: The allowed grid voltage/frequency range when the inverter first time connect to the grid. **Normal Ramp rate**: It is the startup power ramp.

**Reconnect after trip**: The allowed grid voltage /frequency range for the inverter connects the grid after the inverter trip from the grid.

Reconnect Ramp rate: It is the reconnection power ramp.

**Reconnection time**: The waiting time period for the inverter connects the grid again

**PF**: Power factor which is used to adjust inverter reactive power



HV1: Level 1 overvoltage protection point;

1 HV2: Level 2 overvoltage protection point;

LV1: Level 3 overvoltage protection point.

LV1: Level 1 undervoltage protection point;

LV2: Level 2 undervoltage protection point;

LV3: Level 3 undervoltage protection point;

LV4: Level 1 over frequency protection point;

HF1: Level 1 over frequency protection point;


HF2: Level 2 over frequency protection point;

LF1: Level 1 under frequency protection point;

LF2: Level 2 under frequency protection point;

LF3: Level 3 under frequency protection point;


LF3: Level 3 under frequency protection point.



**FW**: this series inverter is able to adjust inverter output power according to grid frequency.

**Droop f**: percentage of nominal power per Hz
For example, "Start freq f > 50.2Hz, Stop freq f < 50.2,
Droop f=40%PE/Hz" when the grid frequency reaches
50.2Hz, the inverter will decrease its active power at
Droop f of 40%. And then when grid system frequency
is less than 50.2Hz, the inverter will stop decreasing
output power.

For the detailed setup values, please follow the local grid code.



**V(W)**: It is used to adjust the inverter active power according to the set grid voltage.

**V(Q)**: It is used to adjust the inverter reactive power according to the set grid voltage.

This function is used to adjust inverter output power (active power and reactive power) when grid voltage changes.

**Lock-in/Pn 5%:** When the inverter active power is less than 5% rated power, the VQ mode will not take effect. **Lock-out/Pn 20%:** If the inverter active power is increasing from 5% to 20% rated power, the VQ mode will take effect again.

For example: V2=110%, P2=20%. When the grid voltage reaches the 110% times of rated grid voltage, inverter output power will reduce its active output power to 20% rated power.

For example: V1=90%, Q1=44%. When the grid voltage reaches the 90% times of rated grid voltage, inverter output power will output 44% reactive output power.

For the detailed setup values, please follow the local grid code.



**P(Q):** It is used to adjust the inverter reactive power according to the set active power.


**P(PF):** It is used to adjust the inverter PF according to the set active power.

For the detailed setup values, please follow the local grid code.

**Lock-in/Pn 50%**: When the inverter output active power is less then 50% rated power, it won't enter the P(PF) mode.

**Lock-out/Pn 50%**: When the inverter output active power is higher then 50% rated power, it will enter the P(PF) mode.

Note: only when the grid voltage is equal to or higher than 1.05times of rated grid voltage, then the P(PF) mode will take effect.



**Reserved:** This function is reserved. It is not recommended.




After setting grid parameters, please select "Lock out all changes" and enter password. If the engineer does not know the password, please contact your distributor or Deye.

#### 5.8.2 Grid Parameter Check

After steps above, customers can see firmware version on main page grid parameters in grid settings on LCD.

#### 5.9 Generator Port Use Setup Menu



**Generator input rated power:** allowed Max. power from diesel generator.

**GEN connect to grid input:** connect the diesel generator to the grid input port.

Smart Load Output: This mode utilizes the Gen input connection as an output which only receives power when the battery SOC and PV power is above a user programmable threshold.

e.g. Power=500W. ON: 100%. OFF=95%: When the PV power.

e.g. Power=500W, ON: 100%, OFF=95%: When the PV power exceeds 500W, and battery bank SOC reaches 100%, Smart Load Port will switch on automatically and power the load connected. When the battery bank SOC < 95% or PV power < 500w, the Smart Load Port will switch off automatically.

#### **Smart Load OFF Batt**

• Battery SOC at which the Smart load will switch off.

#### **Smart Load ON Batt**

also work with "Grid-Tied" inverters.

 Battery SOC at which the Smart load will switch on. Also, the PV input power should exceed the setting value (Power) simultaneously and then the Smart load will switch on.

On Grid always on: When click "on Grid always on" the smart load will switch on when the grid is present.


off grid immediately off: the smart load will stop working immediately when the grid is disconnected if this item is active.

Micro Inv Input: To use the Generator input port as a micro-inverter on grid inverter input (AC coupled), this feature will

- \* Micro Inv Input OFF: when the battery SOC exceeds setting value, Microinveter or grid-tied inverter will shut down.
- \* Micro Inv Input ON: when the battery SOC is lower than setting value, Microinveter or grid-tied inverter will start to work. AC Couple Fre High: If choosing "Micro Inv input", as the battery SOC reaches gradually setting value (OFF), During the process, the microinverter output power will decrease linear. When the battery SOC equals to the setting value (OFF), the system frequency will become the setting value (AC couple Fre high) and the Microinverter will stop working. Stop exporting power produced by the microinverter to the grid.
- \* Note: Micro Inv Input OFF and On is valid for some certain FW version only.
- \* AC couple on load side: connecting the output of on-grid inverter at the load port of the hybrid inverter. In this situation, the hybrid inverter will not able to show the load power correctly.
- \* AC couple on grid side: this function is reserved.
- \* Note: Some firmware versions don't have this function.

### 5.10 Advanced Function Setup Menu





Solar Arc Fault ON: This is only for US.

System selfcheck: Disable. this is only for factory.

Gen Peak-shaving: Enable When the power of the generator exceeds the rated value of it, the inverter will provide the redundant part to ensure that the generator will not overload.

**DRM:** For AS4777 standard (Only DRM0 is available). **Backup Delay:** When the grid cuts off, the inverter will give output power after the setting time.


For example, backup delay: 3ms. the inverter will give output power after 3ms when the grid cuts off.

Note: for some old FW version, the function is not available. BMS\_Err\_Stop: When it is active, if the battery BMS failed to communicate with inverter, the inverter will stop working and report fault.

**Signal ISLAND MODE:** when "signal island mode" is checked and the inverter connects the grid, the ATS port voltage will be 0. When "signal island mode" is checked and the inverter disconnected from the grid, the ATS port voltage will output 230Vac voltage. With this feature and outside NO type relay, it can realize N and PE disconnection or bond.

More details, please refer to left side picture.









**Ex\_Meter For CT:** when in Three phase system with CHNT Three phase energy meter (DTSU666), click corresponding phase where hybrid inverter is connected. e.g. when the hybrid inverter output connects to A phase, please click A Phase.

**Meter Select:** select the corresponding meter type according to the meter installed in the system.

Grid Side INV Meter2: when there's a string inverter AC couple at the grid or load side of hybrid inverter and there's a meter installed for the string inverter, then the hybrid inverter LCD will show the string inverter output power on its PV icon. Please make sure the meter can communicate with the hybrid inverter successfully.







**ATS:** It is related with ATS port voltage. it is better in "uncheck" position.

**Export power limter:** It is used to setup the allowed the maximum output power to flow to grid.

**Import power limiter:** when it is active, the grid output power will be limited. its priority is lower then "grid peak shaving" if the "grid peak shaving" is selected.

**Low Noise Mode:** In this mode, inverter will work in "low noise mode".

Low Power Mode<Low Batt: if selected and when battery SOC is less then "Low Bat" value, the self-consumption power of inverter will be from grid and battery simultaneously. If unselected, the self-consumption power of inverter will be mainly from grid.

**MPPT Multi-Point Scanning:** it will check whether the I/V of PV is working on its Max. power point. If not, then it will adjust I/V to the Max. power point.

### 5.11 Device Info Setup Menu




This page show Inverter ID, Inverter version and alarm codes.

HMI: LCD version


MAIN: Control board FW version

#### 6. Mode


#### Mode I:Basic




#### Mode II: With Generator





#### Mode III: With Smart-Load



#### **Mode IV: AC Couple**









The 1st priority power of the system is always the PV power, then 2nd and 3rd priority power will be the battery bank or grid according to the settings. The last power backup will be the Generator if it is available.

### 7. Fault information and processing

The energy storage inverter is designed according to the grid-connected operation standard and meets the safety requirements and electromagnetic compatibility requirements. Before leaving the factory, the inverter undergoes several rigorous tests to ensure that the inverter can operate reliably.



If any of the fault messages listed in Table 7-1 appear on your inverter and the fault has not been removed after restarting, please contact your local dealer or service center. You need to have the following information ready.

- 1. Inverter serial number;
- 2. Distributor or service center of the inverter;
- 3. On-grid power generation date;
- 4. The problem description (including the fault code and indicator status displayed on the LCD) is as detailed as possible.
- 5. Your contact information. In order to give you a clearer understanding of the inverter's fault information, we will list all possible fault codes and their descriptions when the inverter is not working properly.

Error code	Description	Solutions	
F08	GFDI _Relay_Failure	When inverter is in Split phase(120/240Vac) or three-phase system (120/208Vac) system, the backup load port N line needs to connect ground;     If the fault still exists, please contact us for help.	
F13	Working mode change	1. When the grid type and frequency changed it will report F13; 2. When the battery mode was changed to "No battery" mode, it will report F13; 3. For some old FW version, it will report F13 when the system work mode changed; 4. Generally, it will disappear automatically when shows F13; 5. If still same, and turn off the DC switch and AC switch and wait for one minute and then turn on the DC/AC switch; 6. Seek help from us, if can not go back to normal state.	
F18	AC over current fault of hardware	AC side over current fault  1. Please check whether the backup load power and common load power are within the range;  2. Restart and check whether it is in normal;  3. Seek help from us, if can not go back to normal state.	
F20	DC over current fault of the hardware	DC side over current fault  1. Check PV module connect and battery connect;  2. When in the off-grid mode, the inverter startup with big por load, it may report F20. Please reduce the load power connecte  3. Turn off the DC switch and AC switch and then wait one minute, then turn on the DC/AC switch again;  4. Seek help from us, if can not go back to normal state.	
F22	Tz_EmergStop_Fault	Please contact your installer for help.	
F23	AC leakage current is transient over current	Leakage current fault  1. Check PV side cable ground connection.  2. Restart the system 2~3 times.  3. If the fault still exists, please contact us for help.	

Error code	Description	Solutions
F24	DC insulation impedance failure	PV isolation resistance is too low  1. Check the connection of PV panels and inverter is firmly and correctly;  2. Check whether the PE cable of inverter is connected to ground;  3. Seek help from us, if can not go back to normal state.
F26	The DC busbar is unbalanced	1. Please wait for a while and check whether it is normal; 2. When the hybrid in split phase mode, and the load of L1 and load of L2 is big different, it will report the F26. 3. Restart the system 2~3 times. 4. Seek help from us, if can not go back to normal state.
F29	Parallel CANBus fault	When in parallel mode, check the parallel communication cable connection and hybrid inverter communication address setting;     During the parallel system startup period, inverters will report F29, when all inverters are in ON status, it will disappear automatically;     If the fault still exists, please contact us for help.
F34	AC Overcurrent fault	Check the backup load connected, make sure it is in allowed power range;     If the fault still exists, please contact us for help.
F35	No AC grid	No Utility 1. Please confirm grid is lost or not; 2. Check the grid connection is good or not; 3. Check the switch between inverter and grid is on or not; 4. Seek help from us, if can not go back to normal state.
F41	Parallel system stop	Check the hybrid inverter working status. If there's 1 pcs hybrid inverter is in OFF status, the other hybrid inverters may report F41 fault in parallel system.     If the fault still exists, please contact us for help.
F42	AC line low voltage	Grid voltage fault  1. Check the AC voltage is in the range of standard voltage in specification;  2. Check whether grid AC cables are firmly and correctly connected;  3. Seek help from us, if can not go back to normal state.
F47	AC over frequency	Grid frequency out of range  1. Check the frequency is in the range of specification or not;  2. Check whether AC cables are firmly and correctly connected;  3. Seek help from us, if can not go back to normal state.
F48	AC lower frequency	Grid frequency out of range 1. Check the frequency is in the range of specification or not; 2. Check whether AC cables are firmly and correctly connected; 3. Seek help from us, if can not go back to normal state.
F56	DC busbar voltage is too low	Battery voltage low 1. Check whether battery voltage is too low; 2. If the battery voltage is too low, using PV or grid to charge the battery; 3. Seek help from us, if can not go back to normal state.

Error code	Description	Solutions
F58	BMS communication fault	it tells the communication between hybrid inverter and battery BMS disconnected when "BMS_Err-Stop" is active;     if don't want to see this happen, you can disable "BMS_Err-Stop" item on the LCD;     If the fault still exists, please contact us for help.
F63	ARC fault	ARC fault detection is only for US market;     Check PV module cable connection and clear the fault;     Seek help from us, if can not go back to normal state.
F64	Heat sink high temperature failure	Heat sink temperature is too high 1. Check whether the work environment temperature is too high; 2. Turn off the inverter for 10mins and restart; 3. Seek help from us, if can not go back to normal state.

Chart 7-1 Fault information

Under the guidance of our company, customers return our products so that our company can provide service of maintenance or replacement of products of the same value. Customers need to pay the necessary freight and other related costs. Any replacement or repair of the product will cover the remaining warranty period of the product. If any part of the product or product is replaced by the company itself during the warranty period, all rights and interests of the replacement product or component belong to the company.

Factory warranty does not include damage due to the following reasons:

- · Damage during transportation of equipment;
- · Damage caused by incorrect installation or commissioning;
- Damage caused by failure to comply with operation instructions, installation instructions or maintenance instructions;
- · Damage caused by attempts to modify, alter or repair products;
- · Damage caused by incorrect use or operation;
- · Damage caused by insufficient ventilation of equipment;
- · Damage caused by failure to comply with applicable safety standards or regulations;
- Damage caused by natural disasters or force majeure (e.g. floods, lightning, overvoltage, storms, fires, etc.)

In addition, normal wear or any other failure will not affect the basic operation of the product. Any external scratches, stains or natural mechanical wear does not represent a defect in the product.

### 8. Limitation of Liability

In addition to the product warranty described above, the state and local laws and regulations provide financial compensation for the product's power connection (including violation of implied terms and warranties). The company hereby declares that the terms and conditions of the product and the policy cannot and can only legally exclude all liability within a limited scope.

### 9. Datasheet

Model	SUN-5K- SG02LP1-AU- AM2	SUN-6K- SG02LP1-AU- AM2	SUN-7.6K- SG02LP1-AU- AM2	SUN-8K- SG02LP1-AU- AM2	SUN-10K- SG02LP1-AU- AM3	SUN-12K- SG02LP1-AU- AM3
Battery Input Data						
Battery Type	Lead-acid or Lithium-ion					
Battery Voltage Range(V)		40-60				
Max. Charging Current(A)	120	135	190	190	220	250
Max. Discharging Current(A)	120	135	190	190	220	250
Charging Strategy for Li-Ion Battery		•	Self-adapt	ion to BMS		•
Number of Battery Input			:	1		
PV String Input Data						
Max. PV Input Power(W)	7500	9000	11400	12000	15000	18000
Max. PV Input Voltage(V)		•	50	00		•
Start-up Voltage(V)			12	25		
MPPT Voltage Range(V)			150	-425		
Full Load MPPT Voltage Range(V)	300-425			200-425		
Rated PV Input Voltage(V)			37	70		
Max. Operating PV Input Current(A)	20+20	20+20	26+26	26+26	26+26+26	26+26+26
Max. Input Short-Circuit Current(A)	44+44	44+44	44+44	44+44	44+44+44	44+44+44
No. of MPP Trackers/No. of Strings per MPP Tracker	2/2+2	2/2+2	2/2+2	2/2+2	3/2+2+2	3/2+2+2
Max. Inverter Backfeed Current to The Array			(	)		
AC Input/Output Data						
Rated AC Input/Output Active Power(W)	5000	6000	7600	8000	9999	12000
Max. AC Input/Output Apparent Power(VA)	5000	6000	7600	8000	9999	12000
Peak Power (off-grid)(W)		2	times of rat	ed power, 1	0s	
Rated AC Input/Output Current(A)	21.8	26.1	33.1	34.8	43.5	52.2
Max. AC Input/Output Current(A)	21.8	26.1	33.1	34.8	43.5	52.2
Max. Continuous AC Passthrough (grid to load)(A)	35	40	5	0	6	0
Rated Input/Output Voltage/Range(V)		2	30V/240V 0	.85Un-1.1U	n	
Grid Connection Form			L+N	+PE		
Rated Input/Output Grid Frequency/Range	50Hz/45Hz-55Hz 60Hz/55Hz-65Hz					
Power Factor Adjustment Range	0.8 leading-0.8 lagging					
Total Current Harmonic Distortion THDi	<3% (of nominal power)					
DC Injection Current			<0.5	5%In		
Efficiency						
Max. Efficiency			97.0	50%		
Euro Efficiency			96.	50%		
MPPT Efficiency			>9	9%		
Equipment Protection						
DC Polarity Reverse Connection Protection			Y	es		
AC Output Overcurrent Protection			Y	es		
AC Output Overvoltage Protection	Yes					
AC Output Short Circuit Protection	Yes					
Thermal Protection	Yes					
DC Terminal Insulation Impedance Monitoring	Yes					
DC Component Monitoring	Yes					
Ground Fault Current Monitoring	Yes					

Power Network Monitoring	Yes			
Island Protection Monitoring	Yes			
Earth Fault Detection	Yes			
DC Input Switch	Yes			
Overvoltage Load Drop Protection	Yes			
Residual Current (RCD) Detection	Yes			
Anti-islanding Protection	Yes(Active Frequency Shift)			
Surge Protection Level	TYPE II(DC), TYPE II(AC)			
Interface				
Communication Interface	WIFI, RS485, CAN			
PV Connection	VP-D4			
General Data				
Operating Temperature Range	-40 to +60 ℃ , >45 ℃ Derating			
Permissible Ambient Humidity	0-100%			
Permissible Altitude	2000m			
Noise	<45 dB			
Ingress Protection(IP) Rating	IP 65			
Inverter Topology	Non-Isolated			
Over Voltage Category	OVC II(DC), OVC III(AC)			
Cabinet size(W*H*D) [mm]	420W×670H×233D (Excluding connectors and brackets)			
Weight(kg)	35.6			
Warranty	10 Years			
Type of Cooling	Intelligent Air Cooling			
Grid Regulation	AS/NZS 4777.2			
Safety EMC/Standard	IEC/EN 61000-6-1/2/3/4, IEC/EN 62109-1, IEC/EN 62109-2			

## 10.Package and transport inverter

Usually placed inverter in the packing box with tape sealing, if the inverter cannot reoccupy, you can choose a cheap carton for packaging. Carton requirements must meet the size of the inverter and can support inverter machine overall weight.

Series frequency converter in the process of moving, please note: handle with care, do not touch the inverter, put as flat as possible.


### 11. Disposing of the inverter

Do not dispose of inverter together with household waste. Please accordance with the disposal regulations for electronic waste which apply at the installation site at that time. Ensure that the old unit and, where applicable, any accessories are disposed of in a proper manner.


# 12. Appendix I

#### Definition of RJ45 Port Pin for BMS

No.	BMS 485/CAN Pin
1	485_B
2	485_A
3	GND_485
4	CAN-H
5	CAN-L
6	GND_485
7	485_A
8	485_B



### BMS 485/CAN Port





#### Meter Port

This port is used to connect the energy meter.

Note: some hardware versions hybrid inverter don't support conencting the energy meter


No.	Meter Pin
1	METERB
2	METERA
3	
4	METERB
5	METERA
6	GND_2
7	METERA
8	METERB






#### **DRMs Port**

No.	DRMs Pin
1	DRM1/5
2	DRM2/6
3	DRM3/7
4	DRM4/8
5	REF-GEN/0
6	D-GND
7	NetJ4_7
8	NetJ4_7



### RS232


No.	WIFI/RS232
1	
2	TX
3	RX
4	
5	D-GND
6	
7	
8	
9	12Vdc



WIFI/RS232 This RS232 port is used to connect the wifi datalogger

## 13. Appendix II

- 1. Split Core Current Transformer (CT) dimension: (mm)
- 2. Secondary output cable length is 4m.



Ver: 2.2, 2024-03-18

# NINGBO DEYE INVERTER TECHNOLOGY CO., LTD.

Add.: No.26 South YongJiang Road, Daqi, Beilun, NingBo, China

Tel.: +86 (0) 574 8622 8957 Fax.: +86 (0) 574 8622 8852 E-mail: service@deye.com.cn Web.: www.deyeinverter.com

